

# Ply Backboard Fitting Instructions

Carefully feed the ply up between the metal frame and foam surround.  
Reach up and tuck it under at the top.

